

These fittings are simple to install, as demonstrated by the simple instructions below. However, we always recommend reading the manufacturer's instructions for a more detailed overview.

1. Loosen off the retaining nut.
2. Insert an MDPE pipe liner into the pipe.
3. Push past the O-ring until you hit the stop.
4. Tighten the nut with a universal strap wrench.

